


RUGGED rukus

The All-Terrain, Solar-Powered, Music-
Blasting Wireless Sound System



OWNER'S MANUAL

eton
EMPOWERED BY NATURE

Thank you for purchasing the Etón Rugged Rukus, a portable Bluetooth high-quality sound system featuring solar charging. The Rugged Rukus is powered from the rechargeable Li-ion battery charged by the solar panel or the AC adapter (USB cable included). Please read this user manual to get a good understanding of how the Rugged Rukus works and how to fully rock out with it!

Please visit www.etoncorp.com for latest updates on the manual.

NEED HELP? CONTACT US.

Etón Corporation, 1015 Corporation Way, Palo Alto, CA 94303, USA. 1-800-872-2228 (U.S.); 1-800-637-1648 (Canada); 650-903-3866 (worldwide); M-F, 8:00AM-4:30PM, Pacific Standard Time; www.etoncorp.com.

WARNING

- Do not expose this appliance to rain or moisture.
- Do not submerge or expose for extended period to water.
- Protect from high humidity and rain.
- Only operate within specified temperature range (0 °C to 40 °C).
- Unplug immediately if liquid has been spilled or any object has fallen into the apparatus.
- Clean only with a dry cloth. Do not use detergents or chemical solvents as this might damage the finish.
- Unplug and disconnect external antennas during lightning storms.


- Do not remove cover [or back].
- Refer servicing to qualified service personnel.

ENVIRONMENT

DISPOSAL



According to the European Directive 2002/96/EC all electrical and electronic products must be collected separately by a local collection system.

Please act according to your local rules and do not dispose of your old products with your normal household waste.



Please dispose of all types of batteries per your Government, State or Local rules and/or regulations. If you are unsure, please call the appropriate local authority to find out how to dispose of them safely and help protect the environment.

RUGGED RUKUS FEATURES



FUNCTIONS

- 1 Power ON/OFF button
- 2 Bluetooth button
- 3 Battery indicator icon
- 4 Volume down button
- 5 Volume up button
- 6 Battery life LED indicator
- 7 AUX-in
- 8 Micro USB terminal
(AC/DC power)
- 9 USB Out

CHARGING THE BUILT-IN BATTERY BY THE AC POWER/SOLAR ENERGY

The unit has a built-in Lithium ion battery for portable power when not using the AC/DC power (connected to your smartphone USB AC adaptor - not included, or USB port on your computer). When the adapter is plugged in or the unit is exposed under the sunshine, the unit will start charging. During charging, the Battery Life LED indicator on the display starts blinking.

TO FULLY CHARGE AN EMPTY BATTERY:

AC/DC: 2 to 2.5 hours
Solar: 5 hours*

* Charge times may vary depending on solar conditions.

BATTERY LIFE LED INDICATOR (BUILT IN LITHIUM ION BATTERY)

Press  to check battery level

•	0 - 25 %
••	26 - 50 %
•••	51 - 75%
••••	76 - 100%

USB PORT FOR MOBILE DEVICE CHARGING

The USB jack can be used to charge most devices that allow for USB charging (including many mobile phones, smart phones and wireless headsets).

1. Connect one end of the USB cord to your device and the other end to the USB jack of the unit.

2. Press the  button to start charging for your device.
Press the button again to stop charging.

NOTE: Use the USB power cord that came with your device to connect to the unit. The USB light turns on indicating charging out to USB device

ADJUSTING THE VOLUME LEVEL

Press the  and  buttons to adjust the volume levels.

PLAYING BACK VIA BLUETOOTH

1. Press and hold for 3 seconds ON/OFF  button to turn on the unit. A single blue Battery Life LED light will turn on to indicate the unit is on.
2. Press the Bluetooth button to switch the sound source to Bluetooth mode.

3. Hold the  button for 3 seconds to place the unit in pairing mode. The indicator starts blinking rapidly. Unit will give off two short beeps.

NOTE: The unit beeps once more after the unit is successfully connected.

4. Open the Bluetooth settings menu on your Bluetooth-enabled mobile device or computer and connect it to the Rugged Rukus.
5. Once Bluetooth is connected, select the music and press the  button on your device. The unit will playback music automatically.

NOTE: Playback time on built-in battery is ~8 hours, depending on music level and other factors.

PLAYING BACK VIA AUX

You can enjoy the sound from an external device such as a portable digital music player. Be sure to turn off the power of the external device before making any connections. For details, refer to the instruction manual of the device to be connected.

1. Connect any device with headphone or line out jack with a 3.5mm line in cable to **AUX IN** jack on the back of the unit.
2. Press the  button to turn on the unit.
3. Press the  button to switch the sound source to AUX mode, if the unit is not in AUX mode.

NOTE: The AUX LED light turns on.

4. Turn on your external device and press  button.
5. The unit will play back the music from the external device automatically.

WARRANTY REGISTRATION

To ensure full warranty coverage or product updates, registration of your product should be completed as soon as possible after purchase or receipt. Please go to <http://www.etoncorp.com/productregistration> to register your product.

Please go to <http://http://www.etoncorp.com/productregistration> to register your product.

LIMITED WARRANTY

Retain the warranty information from your warranty card with your proof of purchase or the Limited Warranty information can also be viewed at www.etoncorp.com.

SERVICE FOR YOUR PRODUCT

To obtain service for your product, we recommend first contacting

an etón service representative at 800-872-2228 US, 800-637-1648 Canada or (650) 903-3866 for problem determination and trouble- shooting. If further service is required, the technical staff will instruct how to proceed based on whether the radio is still under warranty or needs non-warranty service.

PRODUCT WARRANTY

Visit <http://www.etoncorp.com/productregistration> to register your product and get warranty information.

WARRANTY

If your product is still in warranty and the etón service representative determines that warranty service is needed, a return authorization will be issued and instructions for shipment to an authorized warranty repair facility. Do not ship your radio back without obtaining the return authorization number.

NON-WARRANTY

If your product is no longer under warranty and requires service our technical staff will refer you to the nearest repair facility that will be able to best handle the repair.

For service outside of north America, please refer to the distributor information included at time of purchase/receipt.

Etón Corporation

Corporate Headquarters
1015 Corporation Way
Palo Alto, California 94303 USA
tel +1 650-903-3866
tel +1 800-872-2228
fax +1 650-903-3867

Etón Canada

5580 Explorer Drive, Suite 503
Mississauga, ON L4W 4Y1 Canada
tel +1 416-214-6885

Designed by Etón Corporation and assembled in China. © Copyright 2013 Etón Corporation. All rights reserved.

v021513



www.etoncorp.com

FCC COMPLIANCE STATEMENT

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC NOTICE

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

INDUSTRY CANADA STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.